

HOW TO SETUP YOUR FANATIC INFLATABLE

USER MANUAL






HOW TO SETUP YOUR FANATIC INFLATABLE



Unpack and unroll your Fanatic Inflatable SUP on a flat surface - grass is ideal.



2

Make sure the valve of the board is in the outer/upper position. The valve must be released for inflation. To release the valve, push slightly downwards and twist to the left or right until you find the upper position.

3

Connect the air hose with a twist to the pump and plug the end piece of the hose into the valve of the board. Turn it clock-wise for a safe connection.


4

Start pumping with your Power Pump switched on double stroke action.



Pump up your board. If it gets too exhausting, switch to single stroke action, it's much easier to reach full pressure with single stroke action.

47




Pump until you reach 15 PSI minimum pressure, for more stiffness you can inflate up to 20 PSI.



HOW TO SETUP YOUR FANATIC INFLATABLE







Place the cap on the valve and close it.



Flip the board over to attach the fin. Use the fin screw to place the little plate at the front of the fin box.



Insert the end of the fin base with the metal pin into the slot of the box and slide it backwards inside of the box, until you can push the front part of the fin base into the fin box.



Use the fin screw to line up the plate hole with the hole in the fin base.



Connect the screw and the plate through the hole. No tools are needed, you're done!



Please have a look at our HOW TO STAND UP PADDLE GUIDE and see how to adjust your paddle and how to use your board on the water. Enjoy!

🔏 🛛 Axeliable on the 📑 🍏 🖸 🚺



PHOTO CREDITS: KLAAS VOGET, MANUEL GRAFENAUER RIDER: ALICE ARUTKIN, BEA SANCHEZ DIAZ, MARÍA ANDRÉS

ALL DATA SUBJECT TO CHANGE © FANATIC 2018 For international distribution contacts please check:

> WWW.FANATIC.COM/WINDSURFING BOARDS & MORE GMBH RABACH 1, A - 4591 MOLLN PHONE: +43 (0)7584 403-0

FANATIC.COM